

## INSTALLATION GUIDANCE

# Chrome ABS Waste Spacer 30mm

B&M SKU: ID0400DI    Idral code: 0400DI

## Installation sequence

- 1 Confirm compatibility with the basin, waste thread, overflow arrangement and available installation space.
- 2 Fit the spacer in the compatible waste assembly shown by the drawing. Maintain adequate thread engagement and the correct seal arrangement.
- 3 Align the waste and trap without forcing the pipework. Tighten evenly without stressing the basin or distorting the seals.
- 4 Run water into the basin and check every joint for leaks. For a closing waste, check opening, closing and overflow drainage where applicable.

## Important

Installation guidance based on the product technical information. Follow the accompanying dimensional drawing and have the work completed by a competent installer.