

INSTALLATION GUIDANCE

Chrome Telescopic Basin Trap

B&M SKU: ID0415-15 Idral code: 0415-15

Installation sequence

- 1 Confirm compatibility with the basin, waste thread, overflow arrangement and available installation space.
- 2 Adjust the telescopic inlet and outlet to align with the basin waste and wall drain. Seat the seals correctly and retain access for cleaning.
- 3 Align the waste and trap without forcing the pipework. Tighten evenly without stressing the basin or distorting the seals.
- 4 Run water into the basin and check every joint for leaks. For a closing waste, check opening, closing and overflow drainage where applicable.

Important

Installation guidance based on the product technical information. Follow the accompanying dimensional drawing and have the work completed by a competent installer.