

INSTALLATION GUIDANCE

Click Clack Waste with Overflow

B&M SKU: ID0419 Idral code: 0419

Installation sequence

- 1 Confirm compatibility with the basin, waste thread, overflow arrangement and available installation space.
- 2 Position the supplied seals and components in the sequence shown by the product drawing. Clean the mating surfaces before assembly.
- 3 Align the waste and trap without forcing the pipework. Tighten evenly without stressing the basin or distorting the seals.
- 4 Run water into the basin and check every joint for leaks. For a closing waste, check opening, closing and overflow drainage where applicable.

Important

Installation guidance based on the product technical information. Follow the accompanying dimensional drawing and have the work completed by a competent installer.