

INSTALLATION GUIDANCE

Chrome Tap Hole Cover 43mm

B&M SKU: ID053 Idral code: 053

Installation sequence

- 1 Check that the cover diameter and fixing arrangement suit the unused tap hole.
- 2 Place the cover over the clean hole with the sealing components correctly positioned.
- 3 Fit the underside clamp and nut. Tighten only enough to hold the cover securely without stressing the basin.
- 4 Check that the cover sits evenly and cannot move.

Important

Installation guidance based on the product technical information. Follow the accompanying dimensional drawing and have the work completed by a competent installer.