

## INSTALLATION INSTRUCTIONS

Square Countertop Basin 45cm Matt Orange  
Product code: AC202600MO

---

### Important safety information

Installation must be completed by a competent person. The installer is responsible for checking the wall, worktop or furniture, selecting suitable fixings and complying with local plumbing and building requirements. Ceramic is heavy and can be damaged by impact or uneven tightening; use two people where needed.

### Before you begin

Check the SKU and finish, compare the product with the technical specification, and confirm that the tap, waste, trap, sealant and fixings are suitable. Protect the basin and surrounding surfaces throughout installation.

### Installation sequence

- 1 Read the technical specification and inspect the basin before installation. Do not install a chipped, cracked or damaged product.
- 2 Confirm that the worktop is level, rigid, water-resistant and able to support the basin when full. Verify tap and waste clearances.
- 3 Dry-position the basin and mark the waste opening and contact area. Use the specification or an approved template for any worktop cut-out; do not trace an unverified opening.
- 4 Prepare the waste and tap where access will be restricted after positioning. Protect the ceramic from tools and metal components.
- 5 Apply a continuous bead of neutral-cure sanitary silicone to the contact surface and place the basin without twisting. Align it and remove excess sealant immediately.
- 6 Connect the waste and trap without placing strain on the ceramic. Complete tap connections in accordance with the tap manufacturer's instructions.
- 7 Allow sealant to cure for the stated time, then run water and inspect every connection for leaks. Recheck that the basin is stable and level.

These instructions provide general guidance. Product-specific dimensions and fixing details shown in the current technical specification take precedence.