

INSTALLATION INSTRUCTIONS

Square Integrated Basin 121cm White
Product code: AC204615W

Important safety information

Installation must be completed by a competent person. The installer is responsible for checking the wall, worktop or furniture, selecting suitable fixings and complying with local plumbing and building requirements. Ceramic is heavy and can be damaged by impact or uneven tightening; use two people where needed.

Before you begin

Check the SKU and finish, compare the product with the technical specification, and confirm that the tap, waste, trap, sealant and fixings are suitable. Protect the basin and surrounding surfaces throughout installation.

Installation sequence

- 1 Confirm that the vanity unit and basin are compatible and that the unit is level, square and securely fixed. Check all dimensions against the technical specification.
- 2 Dry-position the basin and confirm door, drawer, tap, waste and trap clearances. Protect finished furniture surfaces during work.
- 3 Fit the tap and waste before final placement where access will be restricted. Do not overtighten fittings against the ceramic.
- 4 Apply neutral-cure sanitary silicone evenly to the vanity support edges specified by the furniture manufacturer.
- 5 Lower the basin into position, align all edges and remove excess sealant. Support the basin until the sealant has cured.
- 6 Connect the waste and trap without placing strain on the ceramic. Complete tap connections in accordance with the tap manufacturer's instructions.
- 7 Allow sealant to cure for the stated time, then run water and inspect every connection for leaks. Recheck that the basin is stable and level.

These instructions provide general guidance. Product-specific dimensions and fixing details shown in the current technical specification take precedence.