

CARE AND MAINTENANCE

Chrome Basin Pillar Tap

B&M SKU: ID0178 Idral code: 0178

Routine care

- Clean surfaces with water and soap; avoid aggressive liquids and wipe with a soft cloth.
- Water quality affects reliability. Keep the water supply filtered and flush upstream pipework before recommissioning after a shutdown.
- Idral states that mechanical parts normally require no routine maintenance. Arrange inspection if the tap leaks, becomes stiff or its flow changes.
- Keep any flexible hoses accessible, without tension or sharp bends, and away from aggressive substances.
- Protect against freezing; drain residual water before exposure below 5 C.

Service

Use compatible replacement parts. Isolate the water supply before servicing a connected water fitting.