

CARE AND MAINTENANCE

Under Boiler Thermostatic Mixer

B&M SKU: ID09029 Idral code: 09029

Routine care

- Wash exposed surfaces with soap and water, then wipe with a soft cloth.
- Avoid aggressive cleaners, abrasive pads and solvents that may damage the finish.
- Check accessible connections and moving parts regularly. Replace damaged seals or worn components with compatible parts.
- Check the delivered temperature periodically and arrange filter cleaning if flow reduces. Isolate both supplies before servicing.

Service

Use compatible replacement parts. Isolate the water supply before servicing a connected water fitting.