

INSTALLATION GUIDANCE

M21.5 Cache Flow Limiting Kit

B&M SKU: IDKT04LD Idral code: KT04LD

Installation sequence

- 1 Confirm the exact tap-outlet thread and aerator type before removing the existing component.
- 2 Close the tap and protect the basin waste opening so that small parts cannot be lost.
- 3 Use the matching aerator key where required. Remove the existing aerator without scratching the spout.
- 4 Fit the replacement flow limiting insert or assembly with its correct seal. Engage the thread squarely and do not overtighten.
- 5 Run the tap and check for leaks, an even stream and secure seating.

Important

Installation guidance based on the product technical information. Follow the accompanying dimensional drawing and have the work completed by a competent installer.