

CARE INSTRUCTIONS

S18 Back to Wall Rimless with Soft-Close Seat
Product code: AC501802W

Routine ceramic care

- 1 Clean with warm water, diluted mild pH-neutral soap and a soft cloth or non-abrasive sponge.
- 2 Rinse away cleaner residue and dry with a soft cloth to reduce water marks.
- 3 Remove deposits promptly; use only a cleaner expressly suitable for glazed ceramic.

Avoid damage

- 1 Do not use abrasive pads, scouring powders, metal tools, strong acids, alkalis, solvents or steam cleaners.
- 2 Do not mix cleaning chemicals. Never combine bleach with acidic toilet or limescale cleaners.
- 3 Avoid impact from hard objects and do not pour boiling water onto cold ceramic.

Rimless bowl and seat

- 1 Clean the open rinse channel gently with a soft brush; never scrape it with metal tools.
- 2 Clean the soft-close seat with diluted mild soap, rinse and dry. Keep strong disinfectants away from hinges and dampers.
- 3 Do not stand or sit on the closed lid.

Routine checks

- 1 Inspect seals, fixings and plumbing regularly; repair movement or leaks immediately.
- 2 For wall-mounted products, stop use and have the support system inspected if any movement develops.

Important: Always follow the material-specific instructions supplied with cleaners and all sold-separately components. Test unfamiliar cleaners on an inconspicuous area first.